



NAV APPROACH MODES

VOR approaches without a valid DME signal are **prohibited** with autopilot coupled or with flight director in **NAV** or **APP** mode. (*Use Heading Mode and Monitor CDI*)

- **APP Mode** for increased sensitivity On VOR Approaches (with DME)
- **NAV Mode** on LOC Approaches
- LOC BC (Back Course) Place *Front Course* in the PFD Course Selector and Select **BC** on the Flight Director Mode Controller

AFM 2-17 / Honeywell Limitations AFM 2-19.9

ILS APP
VOR/DME APP

LOC NAV
RNAV/GPS NAV

VOR HDG
NDB HDG

BC BC



APPROACH	MODE SELECT	FMA	
ILS	APR	LATERAL	LOC / GS VERTICLE
LOC	NAV		LOC / ALT
BC	BC		BC / ALT
VOR/DME	APR		VAPP / ALT
VOR	HDG		HDG / ALT
RNAV/GPS	NAV		LNAV / ALT
NDB	HDG		HDG / ALT