

AVIONICS TEST PFD INDICATIONS



Avionics / Flight Instruments

- Press the TEST button on the Honeywell Mode selector (LH and RH).
Check to ensure that the system annunciators are functioning correctly:
- Pilot and Copilot radio altimeters display 50 feet.
- Red X displayed in barometric altimeters, airspeed and VSI.
- All digits replaced by dashes (except radio altimeter).
- All error messages are displayed.
- Test message is displayed in upper left corner of PFD.



EXCEL



XLS